
H = door height





L = door width

Mounting System



Place the rear part of the hinge on the front side of the mounting plate.




2 Let the hinge slide on the mounting plate until it stops.



Tighten the connecting screw.

Adjusting System



Front adjustment
Acting on the "A" screw it is
possible to adjust the distance
between the side of the cabinet
and the door.



Independent side adjustment
Acting on the "B" screw it is
possible to change the amount
of the door covering on the side
of the cabinet.



Vertical adjustmentActing on the "C" screw of the mounting plate it is possible to adjust the door vertically.