

# ANCHOR PE

## ADHESIVE FOR FAST ANCHORING

Two-component adhesive for fast anchoring in stone, concrete or brick for static loads and suitable for lower load fixings.

### PROPERTIES

- Fast curing.
- For internal and external use.
- Also suitable at low temperatures, even down to -10 °C, cartridge stored at 20 °C.
- It can be applied with a conventional cartridge gun.
- Simple extrusion and injection.
- It does not slide on vertical surfaces.
- It does not drop, you can use it above head.
- Temperature resistant from - 40 °C to 80 °C.
- Also suitable for filling holes and cracks.
- Exceptional adhesion to all building materials.
- Economic adhesive, excellent ratio between quality and price.

### AREA OF USE

- For fastening anchors supporting normally loads in wall, brick, and concrete.
- As a repair mortar or adhesive for concrete elements.
- As an adhesive for facade elements, wooden structures, metal structures, consoles, fences, sanitary fittings, pipes.
- The adhesive does not swell during curing and is therefore suitable for loads placed near the edges of buildings.
- It is used for the structural adhesion of reinforcing bars and installation of screws in newly built buildings or in the renovation of prefabricated concrete elements.
- Suitable for fixing doors, fences, blinds, antennas, consoles, cable reinforcement, and industrial machines.

### TECHNICAL DATA

#### Fresh adhesive

Curing mechanism:

Appearance:

chemical reaction

A component – light gray paste

B component - black paste

mixture - gray paste



Bonding time/curing time:		
Surface temperature during installation	Bonding time	Minimum curing time in dry concrete **
-10 °C*	50 min	240 min
-5 °C*	40 min	180 min
5 °C	20 min	90 min
15 °C	9 min	60 min
25 °C	5 min	30 min
35 °C	3 min	20 min

\* Adhesive temperature must be at least 20 °C.

\*\* Minimum curing time in wet concrete is doubled.

Full curing after 24 h.

#### Cured adhesive

	Standard	MPa (N/mm <sup>2</sup> )
Compressive strength	EN ISO 604 / ASTM 695	41.8
Flexural strength	EN ISO 178 / ASTM 790	14.1
Flexural module	EN ISO 178 / ASTM 790	2589.6
Tensile strength	EN ISO 527 / ASTM 638	7.4
E Module	EN ISO 527 / ASTM 638	4365.5
VOC Content		A+

#### INSTRUCTION FOR USE

- Mortar and concrete must be older than 28 days. The bore must not be greasy and it has to be thoroughly cleaned with a brush and blown out with air.

Dimensioning of bores for anchor screws:							
Anchor	M8	M10	M12	M16	M20	M24	M30
Anchor diameter (mm)	8	10	12	16	20	24	30
Bore diameter (mm)	10	12	14	18	22	28	35
Bore depth (mm)	80	90	110	125	170	210	280
Distance from the edge (mm)	80	90	110	125	180	220	280
Spacing between anchors (mm)	160	200	240	320	400	450	520
Recommended load in concrete C20/25 -(kN)tensile	8,00	11,21	16,43	23,93	33,93	47,14	62,16
Recommended load in concrete C20 / 25 -(kN)shear	5,14	8,57	12,00	22,29	34,86	50,29	81,43

#### Installation of anchors in massive materials - stone, concrete:

- Drill the bore with an impact drill perpendicular to the surface to the required bore depth.
- Clean the bore well with a round brush, which has a larger diameter than the bore, and blow it out with air.
- We can use a hand pump. Blow out at least 4 times from the bottom of the bore.
- Unscrew the cap, pull the foil from the cartridge, cut it off at the cartridge thread. Screw the static mixer tightly onto the cartridge. Make sure both components are in a static mixer.
- Place the cartridge in the gun and start squeezing. The adhesive is well mixed when it is of a uniform grey colour. The first 10 cm of the mass must not be used for anchoring.
- Fill the bore from the bottom to the top.
- Fill approx. 2/3 of the bore, but ensure that the entire space between the wall and the anchor along the entire depth is filled.

- Make sure the anchor is dry and clean.
- The anchor is pressed into the filled bore while turning it slowly and the adhesive must come out of the bore on the side. Remove excess adhesive.
- Care must be taken to insert the anchor before the open time has elapsed.
- The anchor must not be moved or loaded during curing.

**Installation of anchors in hollow bricks:**

- Drill the holes with a suitable drill.
- Clean the bore well with a round brush, which has a larger diameter than the bore and blow it out with air
- Insert a sleeve with holes of appropriate diameter and length into the bore.
- We do the same as above, except that we fill the entire sleeve with adhesive.

**PACKAGING**

- 300 ml and 165 ml cartridge.

**STORAGE**

18 months at a temperature between +5 °C to +25 °C in the original sealed packaging. Do not expose to direct sunlight.

**HEALTH, SAFETY, HANDLING AND DISPOSAL INFORMATION**

Additional safety information, safe handling instructions, information on personal protective equipment, and disposal information can be found in the safety data sheet. The safety data sheet is available on request. You can also obtain a copy from your TKK sales representative.

**WARNING**

The instructions are based on our tests and practical experience. However, due to specific conditions and working methods we recommend preliminary tests for each application.



**TKK d.o.o.**  
Srpenica 1, 5224 Srpenica, Slovenia  
+386 5 384 13 00, tkk.si